


v10 optic

Dyson V10 Optic logo

User manual

The Dyson V10 Optic™ vacuum



SV12 JN.00000 PN.000000-00-00
00.00.00 EAST VERSION NO.01

Contents

In the box

Getting started Dyson V10 Optic™ vacuum

Changing your click-in battery

Charging your machine with the Wall Dok™

Caring for your floors

Emptying your bin

Changing the bin on your vacuum

Clearing blockages from your vacuum

Washing the Pre-filter

Washing the Post-filter

Washing your Fluffy Optic™ cleaner head

Clearing blockages from your

Mini motorised tool

Cleaning your tools

Looking after your machine


dyson

Dyson logo

In the box


Your machine is boxed in 2 parts:
1. Machine body
2. Cleaner head/tools

Main body showing the handle and bin attached.




Machine body

Simply attach the cleaner head or tool to the front end of the main body or wand.



Fluffy Optic™ cleaner head



Mini motorised tool



Crevice tool



Wand

The charger can be used independently or as part of the dock.

Please note, these are not included when purchased with Auto-empty Dok™.



Charger




The Wall Dok™

Getting started

Dyson V10 Optic™ vacuum

Operating your machine

There are two easy-to-use buttons on the machine. The top button turns your vacuum on and off, while the lower button changes power mode.



The Power and Mode select buttons are adjacent on the top of your vacuum's body, the power button is red and closer to the post-motor filter.

Three power modes

You can cycle between three power modes, depending on floor type and the level of suction needed, using the Mode button.

Eco mode: For longer, lighter cleans

Medium mode: For regular cleaning

Max mode: For stronger suction



Eco



The Eco icon, a tall green battery



Med



The Med icon, a medium-size blue battery



MAX



The Max icon, a short red battery

Clean awkward spaces

Remove the wand and connect your chosen tool directly to the inlet pipe to use the vacuum as a handheld.



Tools and cleaner heads can be attached either to the wand or directly to the main body of your vacuum. If using the wand, it must also be connected to the main body of your vacuum.

Changing your click-in battery

If you have additional click-in batteries, we recommend that you alternate the batteries to maintain even performance.


Removing your battery

Push the Battery release button on the handle and slide the battery off your machine.

Charge the battery.

Refitting your battery

Align your second battery with the handle and slide it in. Push firmly until it clicks into place.



The battery is mounted below the handle of your vacuum

Charging your machine with the Wall Dok™


Allow up to four hours to fully charge your machine before your first use. While your battery is charging, the LED will flash to demonstrate the level of charge. Once your machine is fully charged, the light will turn off.

Battery LED

	Pulsing blue	Machine is charging
	No light	Machine is fully charged
	Flashing blue	Battery fault

Machine LED (Mode button)

	Solid blue, green or red	Normal operation
	Flashing blue, green or red	Battery low
	No light	Battery empty
	Solid orange light	Motor fault
	Flashing orange light	Incompatible tool
	Flashing white light	Cyclone not fitted correctly



Caring for your floors


Check that the underside of the cleaner head or tool is clean and free from any objects that may cause damage.

Before vacuuming your flooring, rugs and carpets, check the manufacturer’s recommended cleaning instructions.

The brush bar on your cleaner head, or mini motorised tool, can damage certain flooring. Some rug materials may fuzz if a rotating brush bar is used when vacuuming. If this happens, we recommend vacuuming without the motorised floor tool and consulting with your flooring manufacturer.

Emptying your bin

Empty as soon as the dirt reaches the MAX level – don't overfill. Using your machine when the dirt is above the top line may affect the performance and require more frequent filter washing. The bin release button is next to the cyclones on the top of your vacuum.




The MAX level mark can be seen on the side of your machine's bin.

Release the dirt


Remove the wand from your machine.

Hold your machine over a bin and pull the bin release catch upwards. The cyclone will slide up and the bin base will open.




Minimise dust contact

Cover your bin tightly in a dust-proof bag while you empty. Remove the bin carefully, seal the bag tightly and dispose.



Close the bin

Push down on the cyclone until it slides into position. Push the bin base upwards until it closes securely.



Cleaning the bin on your vacuum


Empty your bin as soon as the dirt reaches the top mark.

You may need to clean the filter more often if you use your machine with a full bin.

Empty your bin

Remove the wand from your machine.

Hold your machine over a bin and pull the bin release catch upwards. The cyclone will slide up and the bin base will open.




The MAX level mark can be seen on the side of your machine's bin.

Remove the cyclone

Pull the bin release catch upwards. The cyclone will slide up and the bin base will open.

Locate the cyclone release button behind the cyclone and push to remove the cyclone from your machine.



Remove the bin

Pull back on the red catch located on the base, slide the bin down and pull it off your machine.

Clean the bin

Wipe your bin with a damp, lint-free cloth. Don't put the bin in a dishwasher or use detergents, polishes or air fresheners.

Make sure the bin is completely dry before replacing.

Replace the bin

Align the tabs on the bin with the grooves on the main body and slide it upwards until it clicks into place.

Replace the cyclone

Slide the cyclone into the grooves of the main body and push down until it is in position.

Push the bin base up until it clicks firmly shut.


Clearing blockages from your vacuum

Your machine is fitted with an automatic cut-out. If any part of it is blocked, your machine's motor will pulse and won't function until the blockage has been cleared.

Disconnect your machine from the charger before looking for blockages. Be careful not to touch the trigger and be aware of sharp objects.

Leave your machine to cool down before looking for blockages.

Don't use your machine when looking for blockages as this could cause injury.



With the bin open, examine your vacuum for blockages. Pay particular attention in and around the cyclones and the tool/wand attachment point.




With the wand removed from the machine and cleaner head removed from the wand, check for blockages at both ends of the wand. Turn the cleaner head over to check for obstructions on the brush bar and air inlet. Remove any obstructions.

Washing the Pre-filter on your vacuum

Remove your filter

Lift the filter out of the top of the cyclone.

Tap to remove excess dust and debris.




Wash your filter

Hold the open end of the filter under a running tap, until the water runs clear.

Turn the filter upside down and tap it to remove excess water.

Run water over the outside of the filter until the water runs clear.

Squeeze and twist with both hands to make sure the excess water is removed.




Dry your filter


Leave your filter to dry for at least 24 hours in a well-ventilated, warm place.

Do not dry your filter in a tumble-dryer or near a naked flame.

Important: Your filter must be completely dry before you put it back into the machine. Your machine could be damaged if used with a damp filter.




Caution: ensure your filter is fully dry before reinserting to the cyclone.



Refit your filter

Align the arrow on the top of the filter with the bin release button.

Push down to fit securely in place.




Washing the Post-filter on your vacuum

Twist off your filter

Twist your filter anti-clockwise and pull it away from your machine.

The Post-filter is removed from the back of the machine, above the handle.



Wash your filter


Wash the inside of the filter under cold, running water, rotating the filter to make sure all of the inside is clean.

Repeat until the water runs clear.

Shake out the water

Empty the filter and shake firmly to remove excess water.

Keep shaking it until there's no water coming from the filter.




Dry your filter

Place your filter, with the open end facing up, to dry.


Leave your filter to dry for at least 24 hours in a well-ventilated, warm place.

Do not dry your filter in a tumble-dryer or near a naked flame.

Important: your filter must be completely dry before you put it back into the machine. Your machine could be damaged if used with a damp filter.



Caution: ensure your filter is fully dry before reinserting to the cyclone.



Replace your filter


Place your filter on your machine, aligned in the open position.

Twist clockwise until it clicks securely into position.

*Small details may vary


Washing your Fluffy Optic™ cleaner head

Your Fluffy Optic™ cleaner head has a washable brush bar. To maintain optimum performance, check and wash your brush bar regularly. Make sure your machine is disconnected from the charger and take care not to touch the power button.



Remove your brush bar


Don't put any part of your machine in a dishwasher or use detergents, polishes or air fresheners. Press the cleaner head release button on the end of the wand. Place the cleaner head upside down. Push the end cap up fully and pull the brush bar out of the cleaner head. Remove the end cap from the brush bar. Don't wash the end cap.



The end cap is located at the side of the cleaner head, push this upwards to unlock the brush bar. Don't wash the end cap.

Wash and dry your brush bar


Hold your brush bar under running water and gently rub to remove any lint or dirt. Remove as much excess water as possible. Run your hand down the length of the brush bar to squeeze out the water. Stand your brush bar upright, with the closed end at the top. Leave to dry completely for at least 24 hours.



The brush bar has an open end and a closed end. Stand upright, with the closed end facing upwards to dry

Replace your brush bar

Before replacing, check that your brush bar is completely dry. Reattach the end cap to your brush bar. Slide your brush bar into the cleaner head. Push the end cap back down to the closed position.



Cleaning your laser lens

To maintain optimum performance, keep your laser lens clean. Only clean the lens when the cleaner head is not attached to your machine. Use a soft, dry, lint-free cloth to wipe the lens.

The end cap should be attached to the cleaner head at an angle less than 90°, any angle greater than this will not allow the end cap to close

Clearing blockages from your Mini motorised tool

Your Mini motorised tool doesn't have a washable brush bar. To maintain optimum performance, check your brush bar regularly and clear any obstructions.

Make sure your machine is disconnected from the charger and take care not to touch the power button.

Remove your brush bar

Don't put any part of your machine in a dishwasher or use detergents, polishes or air fresheners.

Use a coin to unlock the end cap.

Twist the end cap and remove it from your brush bar. Don't wash the end cap.

Slide your brush bar out of the cleaner head.

Look for obstructions

Clear any debris from your brush bar.

Check inside the cleaner head and remove any debris or blockages.


Your Mini motorised tool and brush bar aren't washable. Wipe over with a damp lint-free cloth.

Replace your brush bar



Push the end cap back on to your brush bar and slide it back into the cleaner head.

Turn the end cap clockwise into the locked position.

Your cleaner head isn't washable and should only be wiped over with a damp lint-free cloth.



Twist the end cap anti-clockwise to remove it from the brush bar



Cleaning your tools

Don't put any part of your machine in a dishwasher or use detergents, polishes or air fresheners.

Wipe with a damp, lint-free cloth, without touching the connector end.

Make sure your tools are completely dry before using.

Crevice tool


Do not wash any cleaner head or motorised tool. They contain electronic components that could be compromised by exposure to water, detergents, polishes or air fresheners.



Crevice tool

Mini motorised tool

Do not wash any cleaner head or motorised tool. They contain electronic components that could be compromised by exposure to water, detergents, polishes or air fresheners.



Mini motorised tool

The Mini motorised tool with an X next to it to signify it is not washable.

Looking after your machine

To always get the best performance from your machine, it's important to clean it regularly and check for blockages.

Day-to-day machine care

If your machine is dusty, wipe with a damp, lint-free cloth.

Look after your battery

For best performance and battery life, only use MAX mode when needed.

Your battery is designed to charge on the dock and stops charging when complete, so returning the machine to the dock after use helps to maintain battery life.

Your machine won't operate or charge if the ambient temperature is below 5°C (41°F). This is designed to protect both the motor and battery.

Where to find your machine's serial number

The serial number is printed on the main body of the machine, behind the back of the clear bin.

Use the serial number to register your machine.

For more information and support videos for your machine, go online: **Dyson.hk**