

hushjet

Purifier Compact

User manual



Contents

Getting started	Set airflow speed
Connecting to the MyDyson™ app via Bluetooth®	Sleep mode
Connecting to your smart home device	Changing your Electrostatic filter
Connectivity	Reset your Electrostatic filter life
Continuous monitoring	Changing your Carbon filter
Information menu	Reset your Carbon filter life
Auto purify	Looking after your machine


dyson

Getting started

Use both hands to lift your machine out of the box, by its base.

Remove all protective packaging, including around the plug and cable.

Plug in and press the Stand-by on/off button on your Dyson air purifier to start/stop your machine. It will continue to monitor the air quality.



Connecting to the MyDyson™ app via Bluetooth®

Take full control with the MyDyson™ app and access step-by-step setup and support, control how and when your Dyson air purifier operates, monitor air quality with visual updates and automatically keep up to date with the latest software updates.



Download the MyDyson™ app from the App Store or Google Play.

Open the app and follow the on-screen instructions to create a new account.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.
App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
Google Play and the Google Play logo are trademarks of Google Inc.



The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License.



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Dyson is under license.

Connecting to your smart home device

Using Amazon Alexa

Ask Alexa to enable the Dyson skill, to control your Dyson purifier or purifier humidifier. And set a routine that automates how your machine works with other devices in your home.



Using Google Assistant

Control all of your connected purifiers with Google or set a routine to automate how your machine works with other devices in your home. Just say "Hey Google" to get started.



Using Siri

Connect your supported Dyson machines to Siri Shortcuts and you'll be able to control them with your voice, on your Apple device.




Connectivity

Wi-Fi and Bluetooth® are turned on by default. To turn the Wi-Fi and Bluetooth® on or off, press and hold the Stand-by on/off button on your machine for five seconds.

The LCD screen will indicate the connectivity status.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Dyson is under license.




Continuous monitoring

Continuous monitoring is turned off by default. You'll need to activate it to start measuring and recording your air quality (AQ) data.

With Continuous monitoring active, your Dyson air purifier will gather air quality information and display it on the LCD screen and in the MyDyson™ app.

Continuous monitoring on/off


You'll be prompted to activate Continuous monitoring on the MyDyson™ app. To turn it on or off from your machine, press and hold the Stand-by on/off button together with the Info button for five seconds. The LCD screen will indicate the Continuous monitoring status.



Information menu

Press this button to scroll through information monitored by your Dyson HushJet™ Purifier Compact air purifier.

Information about air quality, filter levels and Wi-Fi status is shown on the LCD screen.



Indoor air quality

Air quality graph shows the last 12 seconds of data.



Particulate matter (PM2.5)

Microscopic particles up to 2.5 microns in size, suspended in the air we breathe. These include smoke, bacteria and allergens.




Particulate matter (PM10)

Larger microscopic particles up to 10 microns in size, suspended in the air we breathe. These include dust, mould and pollen.



Filters

Remaining filter life on the LCD screen indicates when filters need replacing.



Wi-Fi

The current status of connection to the Wi-Fi network.



Auto purify

Your air purifier is set to Auto mode by default when first switched on. The on-board sensor will intelligently adjust the settings of the machine according to the air quality.

Air quality: Your machine will pause when the target air quality has been reached, switching on again when the air quality levels drop.

Airflow speed: The airflow speed will increase to its maximum until the target air quality has been reached.

AUTO



Set airflow speed

Increase or decrease the airflow speed from your machine or on the MyDyson™ app.

Note: Airflow speed selection from 1 to 10 from the MyDyson™ app.

Low



Medium



High



AUTO



5x

Sleep mode

If your machine is not connected to the MyDyson™ app and doesn't have the latest software.

In Sleep mode, your Dyson air purifier will continue to clean the air quietly, in a lower air flow speed with its LCD screen dimmed.

Press the Sleep timer button from the MyDyson™ app to scroll through the timer options.

To activate Sleep mode, press the Fan button on your machine and then wait for two seconds and the icon will appear.



When activating Sleep mode, the air flow setting will default to speed 4.

The screen will then dim on the machine.

To de-activate Sleep mode, press the Fan button on your machine and then wait for two seconds. The fan speed will then revert to the lowest speed setting.

Low



If your machine is connected to the MyDyson™ app and does have the latest software.

In Sleep mode, your Dyson air purifier will continue to clean the air quietly, in a lower air flow speed with its LCD screen dimmed.

Press the Sleep timer button from the MyDyson™ app to scroll through the timer options.

To activate Sleep mode, press the Fan button on your machine and then wait for two seconds and the icon will appear.




When activating Sleep mode, the air flow setting will default to speed 4.

The screen will then dim on the machine.

Please refer to the section on the previous page "Set air flow speed" on how to change the air flow speed when in Sleep mode.

To de-activate Sleep mode, press the Fan button on your machine and then wait for two seconds and the icon will appear.

If you exit Sleep mode, then the fan speed will revert to Auto.



Changing your Electrostatic filter

The MyDyson™ app and the LCD screen will alert you when your filter life is running low. Replacement filters are available to buy on Dyson.co.uk


Switch off and unplug your Dyson air purifier.

Remove the filter

The Electrostatic filter is located inside your Dyson air purifier. Press the filter release buttons on the side of your machine and lift your machine upwards.

Remove the Carbon filter and put it aside.

Dispose of the Electrostatic filter.




Install a new Electrostatic filter

Remove your replacement filter from any packaging. Place the carbon filter inside the new Electrostatic filter.

Place your machine over the filter. Ensure the slot on the Electrostatic filter aligns with the cable cover on your machine. Slide your machine down until it clicks securely into position.

Plug in, switch on and then reset your filter life.



Reset your Electrostatic filter life

It's important to reset the filter life after replacing your filter.

Press and hold the Fan button.

The LCD screen on your machine will count down from five, then a tick will appear on the screen.

The filter life has been reset, and your machine is ready to use.



Changing your Carbon filter

The MyDyson™ app and the LCD screen will alert you when your filter life is running low. Replacement filters are available to buy on Dyson.co.uk


Switch off and unplug your Dyson air purifier.

Remove the filter

The Carbon filter is located inside the Electrostatic filter. Press the filter release buttons on the side of your machine and lift your machine upwards.

Remove the Carbon filter from the inside of the Electrostatic filter.

Dispose of the Carbon filter.




Install a new Carbon filter

Remove your replacement filter from any packaging. Place your new Carbon filter inside the Electrostatic filter.

Place your machine over the filter. Ensure the slot on the Electrostatic filter aligns with the cable cover on your machine. Slide your machine down until it clicks securely into position.

Plug in, switch on and then reset your filter life.



Reset your Carbon filter life

It's important to reset the filter life after replacing your filter.

Press and hold the Info button.

The LCD screen on your machine will count down from five, then a tick will appear on the screen.

The filter life has been reset, and your machine is ready to use.



5 sec

Looking after your machine

To always get the best performance from your Dyson air purifier, it's important to regularly clean it and check for blockages.

Always remember to switch off and unplug your Dyson air purifier before proceeding with any cleaning.

Cleaning your machine

If your machine is dusty, wipe with a damp, lint-free cloth.

Check the sensor inlets located around the back of your Dyson air purifier for dust and debris.

Look for dust and debris in the machine.

Use a soft brush to remove dust and debris.

Don't use detergents or polishes to clean your machine.



Remove the nozzle

Rotate the nozzle anti-clockwise to unlock.

Lift the nozzle off your machine.

Use a soft brush to remove dust and debris.

The nozzle can be washed. Make sure it is fully dried before reinstalling to your machine.

