


cool

User manual



Contents

In the box

Assembling your machine


Product controls

Cleaning your machine


Clearing blockages

Remote control


In the box




Fan base



Loop amplifier



Remote control



Sleep mode button



Power button and Fan speed dial




Oscillation mode button

Assembling your machine


Step 1

Lower the loop amplifier onto the base, aligning the arrows.



Step 2

Once aligned, turn the loop amplifier clockwise to lock.



Product controls


Power

Press the combined Power button and Fan speed dial, situated in the middle of the controls, to start/stop your machine.




Fan speed control

Turn the combined Power button and Fan speed dial to the right to increase fan speed, turn it to the left to decrease fan speed.




Sleep mode

Press the button on the left to activate Sleep mode. Your fan will blow air at a lower speed and with its LCD screen dimmed.




Oscillation

Press the button on the right to cycle through oscillation angles.
Choose from 10, 40 or 70 degrees.


**Manual tilt**

Carefully hold the base and the top of the air loop amplifier. Tilt forward or backward for the required airflow angle.




Cleaning your machine

Unplug your machine before cleaning. To clean, wipe with a dry or damp cloth. Do not use detergents or polishes to clean the appliance.



Clearing blockages

Look for blockages in the air inlet holes. Use a soft brush to remove debris. Look for blockages in the small aperture inside the loop amplifier. Use a soft brush to remove debris.



Remote control

Use your remote control to operate your machine from a distance.
The remote is curved and magnetised to store neatly on your machine.

Power button

Press the Power button to start or stop your machine.

Fan speed

Press the Fan speed button to increase and decrease the airflow speed.

Oscillation

Press the Oscillation button to circulate the air around the room and scroll through the oscillation angles from 0° to 70°.

Sleep timer

Press the Sleep timer button to scroll through the timer options.

Sleep mode

In Sleep mode, your fan will blow air at a lower speed and with its LCD screen dimmed.

