Regulatory compliance and safety information



IMPORTANT SAFETY INSTRUCTIONS

BEFORE USING THIS LIGHT READ ALL INSTRUCTIONS AND CAUTIONARY MARKINGS IN THE USER MANUAL AND ON THE LIGHT.

When using an electrical appliance, basic precautions should always be followed, including the following:

Δ Warning

These warnings apply to the light, and also where applicable to chargers or mains adaptors.

To reduce the risk of fire, electric shock, or injury:

THIS LIGHT CONTAINS MAGNETS

 Pacemakers and defibrillators may be affected by strong magnetic fields. If you or

2

- someone in your household has a pacemaker or defibrillator, avoid placing near to the device.
- Credit cards and electronic storage media may also be affected by magnets and should be kept away from the light.
- 3. This Dyson light can be used by persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, only if they have been given supervision or instruction by a responsible person concerning use of the light in a safe way and understand the hazards involved. Cleaning and maintenance shall not be performed by children.
- 4. Do not allow to be used as a toy. Close attention is necessary when the light is used near children.
- Ensure light is fully assembled in line with the instructions before use.

- Suitable for indoor use only 0°C (32°F) – 40°C (104°F).
- Use only as described in the Dyson User manual. Do not carry out any maintenance other than that advised by the Dyson Helpline.
- 8. If the light is not working as it should, has received a sharp blow, has been dropped, damaged, left outdoors, or dropped into water, do not use and contact the Dyson Helpline.
- 9. If a service or repair is needed, contact the Dyson Helpline so we can discuss the available options. Do not disassemble the light as incorrect reassembly may result in an electric shock or fire.
 - 10. This light is only to be used with the power supply unit provided with it.
 - 11. Do not handle any part of the light, cable or plug with wet hands.
 - 12. Do not use with a damaged cable or plug. If the supply cable is damaged it must be replaced by Dyson, its service

- agent or similarly qualified persons in order to avoid a hazard.
- Do not stretch the cable or place the cable under strain. Keep cable away from heated surfaces.
- 14. Do not route the cable under furniture or appliances. Do not cover cable with throw rugs, runners or similar coverings. Arrange cable away from traffic area and where it will not be tripped over.
- 15. Do not unplug by pulling on the cable. To unplug, grasp the plug, not the cable. The use of an extension cable is not recommended.
- 16. Turn off all controls before unplugging. Unplug from the socket when not in use for extended periods. To avoid a tripping hazard, safely coil the cable.
- Do not use near furnaces, fireplaces, stoves or other high temperature heat sources.
- The light source is not replaceable; when the light

source reaches its end of life, the whole light shall be replaced. End of life replacement is not covered under the guarantee.

READ AND SAVE THESE INSTRUCTIONS

Additional information

Dyson Link app connectivity

- Dyson endeavours to ensure that our technology is compatible with current operating systems but this is not guaranteed. If you have any questions or would like to check the latest compatibility, please contact the Dyson Helpline.
- Your mobile device must have Bluetooth® wireless technology 4.0 support (Bluetooth Low Energy) in order to set up a connection with the light. Check your device specification for compatibility.
- Plug in your mobile devices to charge up to 1.5A at 5V.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Dyson is under license.

Conformity information

2.4GHz, 10mW max

Hereby, Dyson declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. EC Declaration of Conformity:

www.dyson.co.uk/inside-dyson/terms/compliance

Disposal

- Dyson products are made from high grade recyclable materials.
 Recycle where possible.
- Dispose in accordance with local ordinances or regulations.
- This symbol indicates that this machine should not be disposed with your general household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. When this machine has reached the end of its serviceable life, please toke it to a recognised WEEE (Waste Electrical and Electronic Equipment) collection facility such as your local civic amenity site for recycling. Your local authority or retailer will be able to advise you of your nearest recycling facility.

6

Limited 5-year augrantee

Terms and conditions of the Dyson 5-year limited guarantee

What is covered

- The repair or replacement of your Dyson light (at Dyson's discretion) if it is found to be defective due to faulty materials, workmanship or function within five years of purchase or delivery (if any part is no longer available or out of manufacture, Dyson will replace it with a functional replacement part).
- Where this light is sold outside of the EU, this guarantee will only be valid if the light is used in the country in which it was sold.
- Where this light is sold within the EU, this guarantee will only be valid (i) if the light is used in the country in which it was sold or (ii) if the light is used in Austria, Belgium, France, Germany, Ireland, Italy, Netherlands, Spain or the United Kingdom and the same model as this light is sold at the same voltage rating in the relevant country.

What is not covered

Dyson does not guarantee the repair or replacement of a light where a defect is the result of:

- Damage caused by not carrying out any recommended maintenance of
- Accidental damage, faults caused by negligent use or care, misuse, neglect, carelessness, operation or handling of the light which is not in accordance with the Dyson User manual.
- Use of the light for anything other than the use it is designed for.
- Use of parts not assembled or installed in accordance with the instructions of Dyson.
- Use of parts and accessories which are not genuine Dyson components.
- · Faulty installation (except where installed by Dyson).
- Repairs or alterations carried out by parties other than Dyson or its authorised agents.
- Normal wear and tear (e.g. fuse etc.).

If you are in any doubt as to what is covered by your guarantee, please contact the Dyson Helpline.

Summary of cover

- The guarantee becomes effective from the date of purchase (or the date of delivery if this is later).
- You must provide proof of (both the original and any subsequent) delivery/ purchase before any work can be carried out on your Dyson light. Without this proof, any work carried out will be chargeable. Keep your receipt or delivery note.
- · All work will be carried out by Dyson or its authorised agents.
- Any parts which are replaced by Dyson will become the property of Dyson.
- The repair or replacement of your Dyson light under guarantee will not extend the period of guarantee.
- The guarantee provides benefits which are additional to and do not affect your statutory rights as a consumer.

Important data protection information

You will need to provide us with basic contact information when you register your Dyson light or the Dyson Link app.

When registering via the Dyson Link app:

 You will need to provide us with basic contact information to register the Dyson Link app. This enables us to securely link your light to your instance of the app.

When registering your Dyson light:

- You will need to provide us with basic contact information to register your light and enable us to support your guarantee.
- When you register, you will have the opportunity to choose whether
 you would like to receive communications from us. If you opt-in to
 communications from Dyson, we will send you details of special offers and
 news of our latest innovations.
- We never sell your information to third parties and only use information that you share with us as defined by our privacy policies which are available on our website at privacy.dyson.com.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trademarks of Google Inc.